



# Camtraptions Quick Deploy Camera Trap Manual (*extract*)

## Mounting the Camera Housing

First, assemble the Camera Housing according to its instruction manual.

Position the fully assembled Camera Housing within the centre of the frame, with the Camera Housing's Tube System facing outwards through the front of the Quick Deploy Frame.

Secure the bottom of the Weatherproof Camera Housing to the Frame Base using two 5/16 Inch Button Head Screws.

Secure the side of the Weatherproof Camera Housing using the two 3/8 Inch Button Head Screws, fastening it to the Frame Base and Right Bracket as applicable.

Tighten all four mounting screws using the supplied 4 mm Hex Key. The Camera Housing should be firmly supported, with no movement when gently tested.

Slight pressure may need to be applied to the parts when inserting the two 3/8 Inch Button Head Screws into the side of the assembly, in order to ensure proper alignment of the holes and to allow the 3/8 Inch screws to run cleanly into the threaded inserts of the Camera Housing.

---

Exported from [docs.camtraptions.com](https://docs.camtraptions.com).