





Camtraptions PIR v4 Manual

(extract)



Setting the Operating Mode (Stills or Video)

The **Set Mode** screen allows you to choose whether the sensor operates in **Still Mode** or **Video Mode**. This determines which set of menu screens and settings will be available.



Changing the Operating Mode

1. From the **Home Screen**, press the **Left Arrow** once to reach the **Set Mode** screen.
2. Use the **Up** or **Down** buttons to toggle between:
 - **S** — *Still Mode*
 - **V** — *Video Mode*

Notes

- The **current mode** is always shown on the **Home Screen** as either **S** (Still) or **V** (Video).
- Changing mode will update the available menu screens to show the relevant settings for that mode.

This manual extract applies to firmware version 1.19.

Exported from docs.camtraptions.com.