



Camtraptions Quick Deploy Camera Trap Manual (*extract*)

Safety Notices

The Quick Deploy Camera Trap contains multiple components mounted on an adjustable frame. Take care when carrying, positioning and adjusting the system, particularly when a camera, flashes and batteries are fitted due to the additional weight.

Always support the part of the system you are adjusting before, during and after releasing any thumbscrew, nut or other fastening. Keep fingers clear of moving joints, folding legs and other potential pinch points.

Make adjustments slowly and carefully to avoid injury or damage to the equipment. Adjust one part of the frame at a time. Do not loosen multiple thumbscrews or fastenings simultaneously, as this may allow part of the system to move unexpectedly.

Before leaving the system unattended, check that all clamps, thumbscrews, mounts and legs are securely tightened, and that the Camera Housing, PIR Motion Sensor and Flash Housings are properly supported. Position the system on stable ground or secure it appropriately to prevent it from falling or being dislodged.

Take particular care when working on uneven ground, in wet conditions or at height. Do not place the system where it could create a hazard to people, animals or property.

Use only compatible batteries, cables and accessories, and refer to the individual product manuals for the Camtraptions PIR Motion Sensor v4, Weatherproof Camera Housing, Weatherproof Flash Housing, Z Pro Flash and Camtraptions Wireless Trigger v2 for product-specific safety, battery and operating information.

Exported from docs.camtraptions.com.