



Camtraptions Sony Video Cable v2 Manual (*extract*)

Mode A

Camera is woken, records for **15 seconds** then automatically returns to the powered-down state. Recording time is extended by a further **15 seconds** if there are additional **full-press** signals during the recording period.

How It Works

The input from **full-press** starts the camera recording. Recording stops when **15 seconds** has elapsed since the last **full-press** occurred.

Multi-Sensor Camera Traps

Mode A can be used in a multi-sensor camera trap, where multiple Wireless PIR Sensors can be linked to a single camera to cover different approach paths.

Compatibility

For use with:

- Camtraptions Wireless PIR Sensor v3 (purchased after 18th January 2021), using video programs **1**, **2** or **3**
-

Exported from docs.camtraptions.com.