



Camtraptions Sony Video Cable v2 Manual (*extract*)

Mode B

Full-press starts recording, second **full-press** stops recording.

How It Works

The moment **full-press** is detected the camera is instructed to record. Recording stops only after **full-press** is released and a second **full-press** is detected.

Note: This mode does not auto-power-off the camera after recording. Configure the camera itself to auto-power-off via its menu.

Compatibility

For use with:

- Camtraptions Wireless PIR Sensor v3 (purchased at any time), using video programs **4, 5** or **6**
- Camtraptions PIR Sensor v2 programs **14, 16, 18, 20, 22, 24**
- When manually triggering recordings using a wired or wireless shutter release

